

1075 SCARPro

Scar Configuration



Projector Configuration



SCARPro is a dual mode radiographic exposure device for Small Controlled Area Radiography and traditional radiography.

SCAR

An interchangeable collimator with 90° incremental adjustment enables safe radiography in areas congested with workers.

Projector

A standard guide tube attachment with an ISO compliant interlock enables traditional axial and radial projection radiography



Interchangeable front end plate and collimator

Features

- Interchangeable projector front end plate and SCAR collimator
- Field mode changeable
- Precision machined stainless steel body
- Compact, ergonomic jacket
- Light weight
- Tungsten shield
- ISO 3999 compliant
- Utilizes standard 880 controls and guide tubes

